

Hansa part # 2124

Universal Bucket Seat – fitting to 2.3 or 303

The bucket seat fits in 2.3 and 303 Single and Wide seaters. It rests on the rear aluminium seat tube after removing the standard sling seat. The bucket seat needs to be lashed to the rear seat tube to ensure it stays in place when the boat heels. . If you have a bucket seat and it doesn't have a lashing fitted, note how it is applied in this picture.

Note position of the 4mm hole drilled in the seat flange. Position the hole so the lashing doesn't obstruct the seat tube.

In this picture below we have used 3 mm cord 850mm long - on both sides of seat. The cord has a figure of 8 knot on the inside, with 3 hitches around the flange. The tail of the cord can be passed under the cord next to where it disappears through the hole. The reason why these seats have the big flanges is to ensure the lashing stays on.

